

Innovating Energy Technology

Compact inverter FRENIC-Mini Series



High Performance and Multipurpose

Fully Compatible with Existing Products Easy Operation and Maintenance

New Compact Inverter

High Performance Compact Body. Get Our Most User-Friendly Inverter yet!



NEXT Generation! COMPACT INVERTER FRENIC

FUJI ELECTRIC INVERTERS High Perfomance Compact Body. Welcome to the NEXT Generation of Compact Inverter

With its functionality, compact design, simple operation, and global compatibility, the new FRENIC-Mini elevates the performance of a wide range of devices and equipment--including conveyors, fans, pumps, centrifugal separators, and food processing machines--to give you the system integration, energy efficiency, reduced labor, and lower overall costs you're looking for.

Energy Efficient Network Capabilities Global Compatibility

High Performance and Multipurpose



Dynamic Torque Vector Control System

Fuji Electric original dynamic torque vector control system is known for its top-of-the line performance, delivering stabile torque output even at low speeds. This feature has a wide range of applications, including conveyors and high-inertia loads that demand high starting torque.

Slip Compensation shortens setting time

The slip compensation controller works with voltage tuning for even more accurate speed control at low velocity. This reduces speed control variability and stabilizing creep speed for more accurate stopping in conveyors and similar equipment.

Fastest CPU Processor in its Class

Advanced CPU processes data at twice the speed of our current model



Full Compatibility and User Friendly Design



External dimensions	Interchangeable
Installed dimensions	Interchangeable
Number of terminals	Same for both main circuit and controllers
Terminal position	Compatible terminal wire length
Function codes	Compatible function codes
RS-485 communication	Shared communications protocol

Easy Operation and Maintenance

Usability

Delivers all the usability of the C1. Provides volume of frequency and the same ease of operation as the current model.



Improve Maintainability

Function	Description
Mock malfunction	Select a function to set off a mock alarm
Number of startups	Count the total number of ON/OFF run cycles
Cumulative motor running time	Monitor motor run time
Total power	Set to measure total power consumption
Trip history	Saves and displays information on up to four past trips

•USB Keypad

Optional USB keypad available. Enhanced PC loader software (FRENIC Loader) connectivity.



· FRENIC Loader available as a free download





Power supply

New control system (New FRENIC-Mini)

• PID Control Function

Permits motor operation while controlling temperature, pressure, and flow rate without the use of a temperature controller or other external device

Cooling Fan ON/OFF Control Function

The cooling fan can be switched off when the fan or pump is not running to reduce both noise and energy consumption

Synchronous Motor Control

Use of sensorless synchronous motor control together with the motor can reduce energy consumption

Notwork	Canah	ilition
Network	Capap	illues

• RS-485 Communications Port as Standard

Communications can be controlled through the standard RS-485 communications port using the Modbus-RTU or Fuji Electric inverter protocol



RS-485 Communication Port



Other Features

Functions for User Applications

V/F (non-linear 3 step) Two motor parameter sets Brake signal (brake release signal) Rotational direction control (prevent forward/reverse movement)

Global Standard

EC Directives (CE making)



Variation

Nominal Applied Motor (kW)[HP]	Three-phase 200V series	Three-phase 400V series	Single-phase 200V series	Single-phase 100V series
Standard specifications	3			
Without EMC filter type				
0.1 [1/8]	FRN0001C2S-2		FRN0001C2S-7	FRN0001C2S-6U
0.2 [1/4]	FRN0002C2S-2		FRN0002C2S-70	FRN0002C2S-6U
0.4 [1/2]	FRN0004C2S-2	FRN0002C2S-4	FRN0004C2S-7	FRN0003C2S-6U
0.75 [1]	FRN0006C2S-2	FRN0004C2S-4	FRN0006C2S-70	FRN0005C2S-6U
1.5 [2]	FRN0010C2S-2	FRN0005C2S-4	FRN0010C2S-7	
2.2 [3]	FRN0012C2S-2	FRN0007C2S-4	FRN0012C2S-7	
3.7 [5]	FRN0020C2S-2	FRN0011C2S-4		
5.5 [7.5]	FRN0025C2S-2	FRN0013C2S-4		
7.5 [10]	FRN0033C2S-2	FRN0018C2S-4		
11 [15]	FRN0047C2S-2	FRN0024C2S-4		
15 [20]	FRN0060C2S-2	FRN0030C2S-4		
Destination	A(Asia), U(USA)	A(Asia), C(China), E	E(Europe), U(USA)	U(USA)
Semi-standard specific	ations	_		
EMC filter built-in type				
0.1 [1/8]			FRN0001C2E-7E	
0.2 [1/4]			FRN0002C2E-7E	
0.4 [1/2]		FRN0002C2E-4E	FRN0004C2E-7E	
0.75 [1]		FRN0004C2E-4E	FRN0006C2E-7E	
1.5 [2]		FRN0005C2E-4E	FRN0010C2E-7E	
2.2 [3]		FRN0007C2E-4E	FRN0012C2E-7E	
3.7 [5]		FRN0011C2E-4E		
5.5 [7.5]		FRN0013C2E-4E		
7.5 [10]		FRN0018C2E-4E		
11 [15]		FRN0024C2E-4E		
15 [20]		FRN0030C2E-4E		
Destination		E(Eur	ope)	

How To	Read Model Nu	umber	FRN	0010	C 2	s	 4 A
Code	Series Name				T T		
FRN	FRENIC series						
Applic This value s	able Current Rating shows an amperage rating 0001~0060						
Code	Application Range						
С	Compact						
Code	Developed Inverter Series						
2	2-series						
Code	Enclosure						
S	Standard (IP20) (UL Open Type)						
E	EMC filter built-in type						

—	Code	Destination/Manual
	A	Asia/English
	С	China/Chinese
	E	Europe/English
	U	USA/English
	Code	Input Power Source
	Code 2	Input Power Source Three-phase 200V
	Code 2 4	Input Power Source Three-phase 200V Three-phase 400V
	Code 2 4 6	Input Power Source Three-phase 200V Three-phase 400V Single-phase 100V

Caution

The contents of this catalog are provided to help you select the product model that is best for you. Before actual use, be sure to read the User's Manual thoroughly to assure correct operation.

Standard Model

Specifications

Three-phase 200V series

	Item						S	pecification	ns				
Inpu	ut power source		Three-pha	se 200V									
Тур	0		FRN	C2S-2A,	FRN	C2S-2U							
(FR	NC2S	-2△, △=A, U)											
			0001	0002	0004	0006	0010	0012	0020	0025	0033	0047	0060
Nominal applied motor[kW](△=A			0.1	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
Nor	ninal applied mo	tor[HP](△=U)	1/8	1/4	1/2	1	2	3	5	7.5	10	15	20
	Rated capacity	/[kVA]	0.30	0.57	1.3	2.0	3.5	4.5	7.2	9.5	12	17	22
3gs	Rated voltage	V]	Three-pha	se 200 to 240	V (With AVR)							
ratir	Rated current[A](*1)	0.8(0.7)	1.5(1.4)	3.5(2.5)	5.5(4.2)	9.2(7.0)	12.0(10.0)	19.1(16.5)	25.0(23.5)	33.0(31.0)	47.0(44.0)	60.0(57.0)
Output	Overload capability 150% of rated current for 1m 150% of rated current for 1min or					nin 200% of rated current for 0.5s (If the rated current is in parenthesis) 150% of rated current for 1 min or 200% of rated current for 0.5s							
	Rated frequen	cy[Hz]	50, 60Hz	50, 60Hz									
	Phases, Voltag	e, Frequency	Three-pha	Three-phase, 200 to 240V, 50/60Hz									
ugs	Voltage/Frequency variations Voltage			/oltage: +10 to -15% (Voltage unbalance : 2% or less), Frequency: +5 to -5%									
trat	Rated current[A]	(with DCR)	0.57	0.93	1.6	3.0	5.7	8.3	14.0	21.1	28.8	42.2	57.6
ndu		(without DCR)	1.1	1.8	3.1	5.3	9.5	13.2	22.2	31.5	42.7	60.7	80.0
	Required power su	pply capacity[kVA]	0.2	0.3	0.6	1.1	2.0	2.9	4.9	7.4	10	15	20
p	Torque[%]		150		100		50	30		20			
aki	DC injection b	raking	Starting fre	equency: 0.0 f	to 60.0Hz, Br	aking time: 0	.0 to 30.0s B	raking level:	0 to 100%				
â	Braking transis	tor	-		Built-in								
App	licable safety st	andards	UL508C, E	N 61800-5-1	2007								
Enc	losure (IEC 605	29)	IP20 (IEC	60529:1989)	/ UL open typ	be (UL50)							
Coc	ling method		Natural co	oling			Fan cooling)					
Wei	ight / Mass[kg(It	s)]	0.6(1.3)	0.6(1.3)	0.7(1.5)	0.8(1.8)	1.7(3.7)	1.7(3.7)	2.5(5.5)	3.1(6.8)	3.1(6.8)	4.5(9.8)	4.5(9.8)

*1 The load shall be reduced so that the continuous operating current is the rated current in parenthesis or less if the carrier frequency is set to 3kHz or above or ambient temperature exceeds 40°C (104°F).

Three-phase 400V series

Item						Specifications	3					
Inp	ut power source		Three-phase	Three-phase 400V								
Тур	е		FRN	C2S-4A, FRN	C2S-40	0						
(FRI	N C2S-4/	∆, ∴=A, C, E, U)	FRNC2S-4E, FRNC2S-4U									
			0002	0004	0005	0007	0011	0013	0018	0024	0030	
Nor	ninal applied mo	otor[kW]	0.4	0.75	1.5	2.2	3.7(△=A, C)	5.5	7.5	11	15	
(△=A, C, E)							4.0(△=E)					
Nor	ninal applied mo	tor[HP](△=U)	1/2	1	2	3	5	7.5	10	15	20	
	Rated capacity	/[kVA]	1.3	2.3	3.2	4.8	8.0	9.9	13	18	22	
s	Rated voltage	V]	Three-phase	380 to 480V (W	ith AVR)							
ratir	Rated current[A](*1)	1.8(1.5)	3.1(2.5)	4.3(3.7)	6.3(5.5)	10.5(9.0)	13.0	18.0	24.0	30.0	
Output r	Overload capa	bility	150% of rated 150% of rated curr	d current for 1 mi rent for 1 min or 200%	n 6 of rated current for (rated current for 0.5s (If the rated current is in parenthesis) 200% of rated current for 0.5s						
	Rated frequen	cy[Hz]	50, 60Hz	50, 60Hz								
	Phases, Voltag	e, Frequency	Three-phase,	380 to 480V, 50)/60Hz							
ings	Voltage/Freque	ency variations	Voltage: +10 t	to -15% (Voltage	e unbalance : 29	6 or less), Frequ	uency: +5 to -5%	lo l				
trat	Rated current[A]	(with DCR)	0.85	1.6	3.0	4.4	7.3	10.6	14.4	21.1	28.8	
ndu		(without DCR)	1.7	3.1	5.9	8.2	13.0	17.3	23.2	33.0	43.8	
	Required power su	pply capacity[kVA]	0.6	1.1	2.0	2.9	4.9	7.4	10	15	20	
p	Torque[%]		100		50	30		20				
akir	DC injection b	raking	Starting frequ	ency: 0.0 to 60.	0Hz, Braking tin	ne: 0.0 to 30.0s	Braking level: 0	to 100%				
ā	Braking transis	stor	Built-in									
App	licable safety st	andards	UL508C, EN	61800-5-1:2007								
Enc	losure (IEC 605	29)	IP20 (IEC 605	529:1989) / UL c	pen type (UL50)						
Coo	ling method		Natural coolin	g	Fan cooling							
We	ight / Mass[kg(lt	os)]	1.2(2.6)	1.3(2.9)	1.7(3.7)	1.7(3.7)	2.5(5.5)	3.1(6.8)	3.1(6.8)	4.5(9.8)	4.5(9.8)	

*1 The load shall be reduced so that the continuous operating current is the rated current in parenthesis or less if the carrier frequency is set to 3kHz or above or ambient temperature exceeds 40°C (104°F).

Specifications

Single-phase 200V/100V series

	Item						Specifi	cations					
Inpu	t power source		Single-phas	e 200V					Single-phase	e 100V			
Тур	0		FRN	C2S-7A, FR	N	S-7C			FRN	C2S-6U			
(FRM	C2S-04	△, △ =A, C, E, U)	FRNC2S-7E, FRNC2S-7U										
			0001	0002	0004	0006	0010	0012	0001	0002	0003	0005	
Non	ninal applied mo	otor[kW]	0.1	0.2	0.4	0.75	1.5	2.2	0.1	0.2	0.4	0.75	
(△:	=A, C, E)												
Non	ninal applied mo	tor[HP](△=U)	1/8	1/4	1/2	1	2	3	1/8	1/4	1/2	1	
	Rated capacity	[kVA]	0.30	0.57	1.3	2.0	3.5	4.5	0.26	0.53	0.95	1.6	
gs	Rated voltage[V]	Three-phase	Three-phase 200 to 240V (With AVR)									
ratir	Rated current[A](*1)	0.8(0.7)	1.5(1.4)	3.5(2.5)	5.5(4.2)	9.2(7.0)	12.0(10.0)	0.7	1.4	2.5	4.2	
Output r	Overload capa	bility	150% of rate 150% of rated of	150% of rated current for 1min 50% of rated current for 1min or 200% of rated current for 0.5s (if the rated current is in parenth						ed current for 1 ated current for	lmin or 0.5s		
	Rated frequen	cy[Hz]	50, 60Hz	50, 60Hz									
	Phases, Voltag	e, Frequency	y Single-phase, 200 to 240V, 50/60Hz						Single-phase	e 100 to 120V,	50/60Hz		
ings	Voltage/Freque	ncy variations	Voltage: +10) to -10%, Free	uency: +5 to -	5%							
t rat	Rated current[A]	(with DCR)	1.1	2.0	3.5	6.4	11.6	17.5	2.2	3.8	6.4	12.0	
ndu		(without DCR)	1.8	3.3	5.4	9.7	16.4	24.0	3.6	5.9	9.5	16.0	
-	Required power sup	oply capacity[kVA]	0.3	0.4	0.7	1.3	2.4	3.5	0.3	0.5	0.7	1.3	
6	Torque[%]		150		100		50	30	150		100		
akin	DC injection br	raking	Starting freq	uency: 0.0 to 6	60.0Hz, Brakin	g time: 0.0 to	30.0s, Braking	level: 0 to 100)%				
ä	Braking transis	tor	-		Built-in				-		Built-in		
Арр	licable safety st	andards	UL508C, EN	61800-5-1:20	07				UL508C				
Enc	losure (IEC 605	29)	IP20 (IEC 60	0529:1989) / U	L open type (l	JL50)							
Coo	ling method		Natural cool	ing			Fan cooling		Natural cool	ing			
Wei	ght / Mass[kg(lb	os)]	0.6(1.3)	0.6(1.3)	0.7(1.5)	0.9(2)	1.8(4)	2.5(5.5)	0.7(1.5)	0.7(1.5)	0.8(1.8)	1.3(2.9)	

*1 The load shall be reduced so that the continuous operating current is the rated current in parenthesis or less if the carrier frequency is set to 3kHz or above or ambient temperature exceeds 40°C (104°F).

EMC Filter Built-in Model

Specifications

Three-phase 400V series

	Item					:	Specifications	1				
Inpu	t power source		Three-phase 400V									
Тур	9		FRN	C2E-4E								
(FRI	N	4E)	0002	0004	0005	0007	0011	0013	0018	0024	0030	
Non	ninal applied mo	tor[kW]	0.4	0.75	1.5	2.2	4.0	5.5	7.5	11	15	
Nominal applied motor[HP]			1/2	1	2	3	5	7.5	10	15	20	
	Rated capacity	[kVA]	1.3	2.3	3.2	4.8	8.0	9.9	13	18	22	
ß	Rated voltage[V]	Three-phase 3	380 to 480V (Wi	th AVR)							
ratir	Rated current[/	A](*1)	1.8(1.5)	3.1(2.5)	4.3(3.7)	6.3(5.5)	10.5(9.0)	13	18	24	30	
Output	Overload capal	bility	150% of rated 150% of rated curr	current for 1 min ent for 1 min or 200%	of rated current for 0.5s (If the rated current is in parenthesis) 200% of rated current for 0.5s			n or				
	Rated frequency[Hz] 50, 60Hz											
	Phases, Voltag	e, Frequency	Three-phase,	ree-phase, 380 to 480V, 50/60Hz								
ings	Voltage/Frequency variations		Voltage: +10 to -15% (Voltage unbalance : 2% or less), Frequency: +5 to -5%									
t rat	Rated current[A]	(with DCR)	0.85	1.6	3.0	4.4	7.3	10.6	14.4	21.1	28.8	
ndul		(without DCR)	1.7	3.1	5.9	8.2	13.0	17.3	23.2	33.0	43.8	
	Required power sup	ply capacity[kVA]	0.6	1.1	2.0	2.9	4.9	7.4	10	15	20	
g	Torque[%]		100		50	30		20				
rakir	DC injection br	aking	Starting freque	ency: 0.0 to 60.0)Hz, Braking tim	e: 0.0 to 30.0s	Braking level: 0	to 100%				
æ	Braking transis	tor	Built-in									
App	licable safety sta	andards	UL508C, EN 6	61800-5-1:2007								
App (EN (in p	licable EMC sta 61800-3:2004 + rogress)	ndards A1:2012)	Immunity : Se Emission : Ca	cond Environme tegory C2	ent (Industrial)			Immunity : Se Emission : Ca	cond Environme tegory C3	ent (Industrial)		
Enc	losure (IEC 605	29)	IP20 (IEC 605	29:1989) / UL o	pen type (UL50))						
Coo	ling method		Natural coolin	g	Fan cooling							
Wei	ght / Mass[kg(lb	s)]	1.5(3.3)	1.6(3.5)	3.0(6.6)	3.1(6.8)	3.2(7.1)	4.6(10.1)	4.6(10.1)	6.7(15)	6.7(15)	

*1 The load shall be reduced so that the continuous operating current is the rated current in parenthesis or less if the carrier frequency is set to 3kHz or above or ambient temperature exceeds 40°C (104°F).

Single-phase 200V series

	Item				Specifi	cations					
Inpu	it power source		Single-phase 200V								
Тур	e		FRNC2E-7E								
(FR	N	7E)	0001	0002	0004	0006	0010	0012			
Nor	ninal applied mo	tor[kW]	0.1	0.2	0.4	0.75	1.5	2.2			
Nominal applied motor[HP]			1/8	1/4	1/2	1	2	3			
	Rated capacity	[kVA]	0.30	0.57	1.3	2.0	3.5	4.5			
ß	Rated voltage[V]	Three-phase, 200 to 2	240V, 50/60Hz							
ratir	Rated current[/	A](*1)	0.8(0.7)	1.5(1.4)	3.5(2.5)	5.5(4.2)	9.2(7.0)	12.0(10.0)			
Output	Overload capa	bility	150% of rated current 150% of rated current	for 1min for 1min or 200% of rat	ed current for 0.5s (If th	e rated current is in par	enthesis)				
	Rated frequency[Hz] 50, 60Hz										
	Phases, Voltage, Frequency Single-phase, 200			240V, 50/60Hz							
ings	Voltage/Frequency variations		Voltage: +10 to -10%, Frequency: +5 to -5%								
t rat	Rated current[A]	(with DCR)	1.1	2.0	3.5	6.4	11.6	17.5			
ndu		(without DCR)	1.8	3.3	5.4	9.7	16.4	24.0			
	Required power sup	oply capacity[kVA]	0.3	0.4	0.7	1.3	2.4	3.5			
8	Torque[%]		150		100		50	30			
akir	DC injection br	aking	Starting frequency: 0.	0 to 60.0Hz, Braking tim	e: 0.0 to 30.0s, Braking	level: 0 to 100%					
m	Braking transis	tor	-		Built-in						
App	licable safety st	andards	UL508C, EN 61800-5	-1:2007							
App (EN (in p	licable EMC sta 61800-3:2004 + progress)	ndards A1:2012)	Immunity : Second Er Emission : Category C	wironment (Industrial)							
Enc	losure (IEC 605	29)	IP20 (IEC 60529:1989	9) / UL open type (UL50)						
Coo	ling method		Natural cooling				Fan cooling				
Wei	ght / Mass[kg(lb	s)]	0.7(1.5)	0.7(1.5)	0.8(1.8)	1.2(2.6)	3.0(6.6)	3.0(6.6)			

*1 The load shall be reduced so that the continuous operating current is the rated current in parenthesis or less if the carrier frequency is set to 3kHz or above or ambient temperature exceeds 40°C (104°F).

Common Specifications

Common Specifications

		Item		Explanation	Remarks						
		Maximum frequency	25 to 400Hz								
	æ	Base frequency	25 to 400Hz								
	ang	Starting frequency	0.1 to 60.0Hz								
ut frequency	Setting r	Carrier frequency	0.75 to 16kHz Note: The unit is equipp protect the inverter whe other conditions. (*1) • Under modulated carr	bed with an automatic reduction/stop function that may automatically drop the carrier frequency to in it is running at frequencies above 6 kHz, depending on ambient temperature, output current, and ier conditions, the system scatters carrier frequency to reduce noise							
Outpt	Ac	ccuracy (stability)	Analog setting: : Al Keypad setting: : Al	bsolute accuracy within $\pm 2\%$ (at $25^{\circ}C(77^{\circ}F)$), temperature drift within $\pm 0.2\%$ ($25^{\circ}C(77^{\circ}F) \pm 10^{\circ}C(50^{\circ}F)$) bsolute accuracy within $\pm 0.01\%$ (at $25^{\circ}C(77^{\circ}F)$), temperature drift within $\pm 0.01\%$ ($25^{\circ}C(77^{\circ}F) \pm 10^{\circ}C(50^{\circ}F)$)							
	Setting resolution		Analog setting : 1/1000 of maximum frequency Keypad setting : 0.01Hz (99.99Hz or less), 0.1Hz (100.0Hz to 400.0Hz) Link operation : 1/20000 of maximum frequency or 0.01Hz (fixed)								
	Co	ontrol method	Induction motor drive · V/f control · Slip com · Dynamic torque vector	pensation - Automatic torque boost r control - Automatic energy-saving function							
			Synchronous motor driv · Sensorless magnetic p	re positioning (speed control range: 10% of base frequency and up)							
			200V series Base freq AVR contr Allowable	uency and maximum output frequency can each be set between :80 to 240 ol (*1) can be turned ON or OFF non-linear V/f (*1) settings (2): optional voltage (0-240V) and frequency (0-400Hz)							
	Vo	oltage/freq. characteristic	Allowable non-linear V/I (*1) settings (2): optional voltage (0-240V) and frequency (0-400Hz) Base frequency and maximum output frequency can each be set between :160 to 500 AVR control (*1) can be turned ON or OFF Allowable non-linear V/I (*1) settings (2): optional voltage (0-500V) and frequency (0-400Hz)								
			Automatic torque boost (for constant torque loads)								
	Torque boost (*1)		Manual torque boost: Optional torque boost value can be set between 0.0 and 20.0%								
			Application load can be selected (for constant and variable torque loads)								
	St	arting torque (*1)	150% or more/frequency set to 3Hz. Slip compensation /automatic torque boost active								
			Keypad operation	: Start and stop with (RUN), 500 keys (standard keypad) : Start and stop with (RUN), 500 keys (remote keypad: optional)							
	Sta	art/stop	External signals (digital input)	: FWD (REV) operation/stop command [3-wire operation enabled] Coast-to-stop command, trip command (external fault), fault reset, etc.							
Itrol			Link operation	: Communication via RS-485							
ð			Changing run command	: Communications used to change run command							
			Keypad operation Also can be set with fur	: Can be set with or very (with save data function)							
			Set based on built-in vo	lume							
				: 0 to +10V DC/0 to 100% (terminal 12)							
			Analog input	: 4 to +20mA DC/0 to 100%, 0 to +20mA DC/0 to 100% (terminal C1)							
	Fr	equency setting	Multistep frequency	: Selectable from 16 steps (step 0 to 15)							
			UP/DOWN operation	: Raises or lowers frequency while digital input signal is ON							
			Link operation:	: Frequency set through RS-485 communication							
			Changing frequency settings	: Two types of frequency settings can be changed using external signals (digital input) : frequency settings and multistep frequency settings							
			Auxiliary frequency setting	: Built-in potentiometer, Inputs at terminal 12, C1 can be added to the main setting as auxiliary frequency settings.							
			Inverse operation	: Can be switched from (DC 0 to +10V/0 to 100%) to (DC +10 to 0V/0 to 100%) externally : Can be switched from (DC 4 to 20mA (DC 0-20mA)/0 to 100%) to (DC 20 to 4mA (DC 20-0mA)/0 to 100%) externally							
	Acc	celeration/deceleration time	Can be set between 0 There are two indepen Pattern : The following Linear, S-curve (weak Coast-to-stop accelerat Acceleration/decelerat	00 and 3600s dent settings that can be selected for acceleration/deceleration time (can be switched while running) four acceleration/deceleration types can be selected /strong), non-linear (constant output maximum capacity acceleration/deceleration) tilon/deceleration is enabled when run commands are OFF ion time can be set during jogging operation (between 0.00 and 3600s)							

*1 Only valid when induction motor drive is in operation

Common Specifications

Common Specifications

	Item Explanation								
	Frequency limiter (Peak/bottom frequency limit)	High and low limiters can be set in addition to Hz values (0-400Hz)							
	Bias frequency	Bias of set frequency and PID command can be set separately between 0 and ±100%							
	Gain for frequency setting	Analog input gain can be set between 0 and 200%							
Jump frequency control Three operation points and their common jump hysteresis width can be set (0–30Hz) Six operation points and their common jump hysteresis width can be set (0–30Hz) (*2)									
	Timer operation	Operation starts and stops at the time set from keypad (1 cycle)							
	Jogging operation (*1) Operated using the we (on the standard or remote keypad) or digital contact point input (acceleration and deceleration timesame duration used only for jogging)								
	Auto-restart after momentary power failure (*1)	Trip at power failure: The inverter trips immediately after power failure. Trip at power recovery: Coast-to-stop at power failure and trip at power recovery Deceleration stop: Deceleration stop at power failure, and trip after stoppage (*2) Start at the frequency selected before momentary stop: Coast-to-stop at power failure and start after power recovery at the frequency selected before momentary stop. Start at starting frequency: Coast-to-stop at power failure and start at the starting frequency after power recovery.							
Current limit Uses hardware to limit current and prevent overcurrent trips resulting from sudden load changes, momentary power failures, and similar events that cannot be handled by software current limiters (can be canceled)									
Itrol	Slip compensation (*1)	Compensates for decrease in speed according to the load, enabling stable operation							
ő	Current limit	Keeps the current under the preset value during operation							
PID control PID command, keyboard, analog input (terminal 12, C1), RS-485 communication · Feedback value: Analog input (terminal 12, C1) · Low liquid level stop function · Switch forward/reverse operation · Integration reset/hold function									
	Automatic deceleration	 Automatically limits output frequency, limits energy generated by the inverter, and avoids overcurrent trips when torque relay value is exceeded (*1) Makes deceleration time three times longer to avoid <i>JU</i> trip when DC link circuit voltage exceeds overage limit 							
Deceleration characteristics (improved braking capacity) Increases motor loss and reduces energy generated by the inverter during deceleration to avoid overcurrent trips									
	Energy saving operation (*1)	Restricts output voltage to minimize total motor and inverter loss during constant speed operation							
	Overload prevention control	Lowers frequency when IGBT junction temperature and ambient temperature rise due to overloading to avoid further overload							
	Offline tuning (*1)	Performs r1, X σ , and excitation current tuning Performs r1, X σ , slip frequency and excitation current tuning (*2)							
	Fan stop operation	Detects inverter internal temperature and stops cooling fan when the temperature is low							
	Secondary motor settings	Switching between two motors in the same inverter is enabled (switching cannot be performed while the inverter is running) Induction motor settings can only be applied to the second motor Data settings (base frequency, rated current, torque boost, electronic thermal, and slip compensation, etc.) can be entered for the second motor Constants can be set within the second motor. Auto-tuning is also enabled.							
	Rotational direction limits	Select either prevent reverse or prevent forward operation							
	Running/stopping	Speed monitor, output current [A], output voltage [V], input power [kW], PID reference, PID feedback value, PID output, timer value (for timer operation) [s], total power amount Select the speed monitor to be displayed from the following: Output frequency (before slip compensation) [Hz], output frequency (after slip compensation) [Hz], set frequency [Hz], load shaft speed [min ⁻¹], line speed [m/min], constant rate of feeding time [min]							
	Lifetime alarm	Displays the lifetime alarm for the main circuit condenser, PCB condenser, and cooling fan. External output is enabled for lifetime alarm information.							
	Total running time	Can display total motor running time, total inverter running time, and total power use							
	I/O check	Displays control circuit terminal output status							
_	Energy saving monitor	Power consumption, power consumption x coefficient							
Indication	Trip mode	Displays cause of trip: $B \subseteq I$: Overcurrent during acceleration $B \subseteq 2$: Overcurrent during deceleration $B \subseteq 3$: Overcurrent at constant speed L_{IRC} : Input phase loss LU : Undervoltage $B \subseteq 3$: Overcurrent at constant speed UII : Overvoltage during acceleration $UU2$: Overvoltage during deceleration $UU3$: Overvoltage during constant speed UII : Overheating of the heat sink $BH2$: External thermal relay tripped $BH4$: Motor protection (PTC thermistor) dbH : Overheating of the DB circuit E_{OF} : PID feedback break detected BLI : Overload in motor 1 $DL2$: Overload in motor 2 BLU : Inverter unit overload $E_{C}I$: Memory error $E_{C}2$: Keypad communication error $E_{C}3$: CPU error $E_{C}5$: Operation procedure error $E_{C}7$: Tuning error $E_{C}8$: RS485 error $E_{C}F$: Data save error due to undervoltage $E_{C}d$: Step out detected (for synchronous motor drive) ("2) $E_{C}r$: Mock error							
	Running or Trip mode	Trip history: Saves and displays the last 4 trip codes and their detailed description Saves and displays detailed data for each section on up to four past trips							

*1 Only valid when induction motor drive is in operation

*2 These functions can be supported by the inverters having a ROM version 0500 or later

Common Specifications

	Explanation	Remarks								
	Overcurrent	Stops the inverter to	protect against overcurrent due to overload	LED display						
	Short-circuit	Stops the inverter to	protect against overcurrent due to a short circuit in the output circuit	0C1 0C2						
	Ground fault	Stops the inverter to protect against overcurrent due to a ground fault (initial ground circuit only) in the output circuit								
	Overvoltage	Detects excess volt Cannot protect agai	age in DC link circuit (200V: DC 400V,400V: DC 800V) and stops the inverter inst significantly large voltage input mistakenly applied	OU1 OU2 OU3						
	Undervoltage	Detects drops in DC Note that no alarm w	link circuit voltage (200V: DC 200V,400V: DC400V) and stops the inverter vill sound if auto-restart after momentary power failure is selected	LU						
	Input phase loss	Stops or protects the Even when there is inp	e inverter against input phase loss out phase loss, the loss may not be detected if the connected load is light or a DC reactor is connected to the inverter	Lin						
	Output phase loss detected	Detects loss from br	eaks in output wiring while running or during startup and stops the inverter	OPL						
Stops the inverter by detecting the temperature of the inverter cooling system (e.g. when the cooling fan is malfunctioning or there is an overload)										
	Overneating	Protects against ove	rheating during braking resistance based on braking resistor electronic thermal function settings	dbH						
Overload Stops the inverter based on the temperature of the cooling system and the switching element calculated from output current flow										
	External alarm input	Stops the inverter al	arm through digital input (THR)	OH2						
	Electronic thermal	Stops running the im Protects the standar protected. (Operation	verter to protect the motor according to electronic thermal function settings d motor and inverter motor over the full frequency range. The second motor can also be n level and thermal time constant can be set between 0.5 and 75.0 minutes)	OL1 OL2						
	PTC thermistor	Stops running the in A PTC thermistor is of	nverter to protect the motor when the PTC thermistor detects motor temperature onnected between terminals C1 and 11, and a resistor is connected between terminals 13 and C1. Set function code.	OH4						
_	Overload early warning	Outputs a preliminar	y alarm at a preset level before the electronic thermal stops the inverter	-						
6	Memory error	Checks data when the	he power is turned on and data is being written, and stops the inverter if a memory malfunction is detected.	Er1						
Prote	Keypad communication error	Stops the inverter if a command is in progr	a communication malfunction is detected between the keypad and inverter unit while an operation ress from the remote keypad	Er2						
	CPU error	Stops the inverter if a	a CPU malfunction caused by noise or similar factors is detected	Er3						
	Operation error	wey priority	Pressing the seven the keypad forces the inverter to stop, even if run commands are being delivered via terminals or communications. Er6 is displayed once stop is complete.	Fr6						
		Prohibits run operations and displays Er6 if a run command is given while any of the following status changes are occurring: Start check · Powering up · Canceling an alarm · Switching run command methods via link operation								
	Tuning error (*1)	Stops the inverter w	hen there is a tuning failure, interruption, or abnormality in tuning results during motor constant tuning	Er7						
	RS-485 communication error	Stops the inverter if	a communications malfunction is detected in RS-485 communication with the inverter unit	Er8						
	Data save error during undervoltage	Displays an error if o	data save cannot proceed normally because an undervoltage protection function is activated	ErF						
	Step out detected (*2)	Stops the inverter w	hen a synchronous motor step out is detected	Erd						
	PID feedback break detected	Stops the inverter wh	en a break is detected during current input (C1 terminal) distribution to PID feedback (can be enabled/disabled)	CoF						
	Stall prevention	Output frequency is redu	ced to avoid an overcurrent trip when output current exceeds the limit during acceleration/deceleration or constant speed operation							
	Alarm output (for any fault)	Outputs a relay signal when the inverter is stopped due to an alarm Alarm stop status can be canceled by pressing the PRG/RESET key or by inputting a digital signal (RST)								
	Retry	Inverter can be autom	atically reset and restarted after stopping due to a trip (the number of retries and wait time until reset can also be set)							
	Incoming surge	Protects the inverter	from surge voltage between the main circuit and ground terminal							
	Momentary power failure	Launches a protect Restarts and restor	tive function (stops the inverter) when there is a momentary power failure of 15ms or more res voltage within the set time when momentary power failure restart is selected							
_	Mock malfunction	Can output a mock a	alarm to check malfunction sequences	Err						
	Installation location	Must be indoors an Keep out of direct s	Ind free of corrosive gases, flammable gases, dust, and oil mist (contamination level 2 (IEC 60664-1: 2007) sunlight							
	Ambient temperature	Open: -10°C (14°F)	to + 50°C (122°F) (IP20)							
But	Ambient humidity	5 to 95%RH (no con	idensation)							
Environme	Altitude	1000m (3300ft) or le Above 1000m (3300 Above 1000m (3300 Above 1000m (3300	es (Output derating is not necessary.) Ift) to 3000m (9800ft) or less (Output derating is necessary.) Ift) to 1500m (4900ft) or lower : 0.97, Above 1500m (4900ft) to 2000m (6600ft) or lower : 0.95, Ift) to 2500m (8200ft) or lower : 0.91, Above 2500m (8200ft) to 3000m (9800ft) lower : 0.88							
	Vibration	3mm (0.12inch) (vibrat	tion width): 2 to less than 9Hz, 9.8m/s ² : 9 to less than 20Hz, 2m/s ² : 20 to less than 55Hz, 1m/s ² : 55 to less than 200Hz							
	Saved temperature	-25°C (77°F) ± 70°C	: (158°F)							
	Saved humidity	5 to 95%RH (no con	95%RH (no condensation)							

*1 Only valid when induction motor drive is in operation *2 These functions can be supported by the inverters having a ROM version 0500 or later

Terminal Functions

Terminal Functions

Category	Symbol Terminal Name Functions		Remarks	
• ·	L1/R,L2/S,L3/T	Power input	Connect a three-phase power supply (three-phase 200V,400V)	
	U,V,W	Inverter output	Connect a three-phase induction motor	
in	P(+) ,P1	For DC REACTOR	Connect the DC REACTOR	
n circ	P(+) ,N(-)	For DC bus connection	Used for DC bus connection system	
Mai	P(+) ,DB For EXTERNAL BRAKING RESISTOR Connect e		Connect external braking resistor	Only for 0.4kW and above. Connections are enabled for 0.2kW and below, but operation will not work.
	OG(2-terminal)	Grounding	Ground terminal for inverter chassis	
	13	Potentiometer power supply	Power supply for frequency setting potentiometer (1 to $5k\Omega$)	DC10V
		Voltage input	Used as voltage input for frequency setting 0 to +10V DC/0 to 100%	
setting	12	(Inverse operation) (PID control) (Frequency aux. setting)	++10 to +0V DC/0 to 100% Used for reference signal (PID process command) or feedback signal Used as additional auxiliary setting to various main settings of frequency	
duency		Current input	Used as current input for frequency setting +4 to +20mADC (0 to +20mADC)/0 to 100%	
Fre	C1	(Inverse operation) (PID control) (Frequency aux. setting)	+4 to +20mA DC (0 to +20mA DC)/0 to 100% Used for reference signal (PID process command) or feedback signal Used as additional auxiliary setting to various main settings of frequency	
		(For PTC thermistor)	Connects PTC thermistor for motor protection	
	11(2-terminal)	Common	Common terminal for frequency setting signal (12, 13, C1, FMA)	Isolated from terminal CM and Y1E
	X1	Digital input 1	The following functions can be set at terminals X1 to X3, FWD,	
	X2 Digital input 2		and REV for signal input.	
	X3	Digital input 3	 Switch between synch/source using the built-in switches on the unit 	
	FWD	Forward operation command	Short-circuit ON or open circuit ON settings are enabled between the terminal X1 and CM	
	REV	Reverse operation command	The same setting is possible between CM and any of the terminals among X2, X3, FWD, and REV.	
	(FWD)	Forward operation command	The motor runs in the forward direction when (FWD) is ON, stops after deceleration when FWD is OFF	Only terminal FWD/REV settings are allowed, only short circuit ON
	(REV)	Reverse operation command	The motor runs in the reverse direction when (REV) is ON, stops after deceleration when REV is OFF	do.
input	(SS1) (SS2) (SS4) (SS8)	Multistep freq. selection	16-speed operation is enabled using the ON/OFF signal from (SS1) through (SS8) Frequency Digital input 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 (SS1) ON ON	
Digital	(RT1)	ACC/DEC selection	Acceleration/deceleration time setting 1 is active when RT1 is OFF Acceleration/deceleration time setting 2 is active when RT1 is ON	
	(HLD)	3-wire operation stop command	Used as an automatic hold signal during 3-wire operation The FWD or REV signal is automatically stopped when HLD is ON, and the hold is removed when HLD is OFF	
	(BX)	Coast-to-stop command	When BX is ON, inverter output is shut off immediately and the motor coasts-to-stop (no alarm output)	
	(RST)	Alarm reset	Alarm hold status is removed when RST is ON	Signal at 0.1s or higher
	(THR)	Trip command (External fault)	When THR is OFF, inverter output is shut off immediately and the motor coasts-to-stop (alarm output enabled: OH2)	
	(JOG)	Jogging operation	Turn JOG ON to enable jogging operation: switches the running mode to jogging mode, the frequency setting to jogging frequency, and acceleration/deceleration time to jogging running use	(*1)
	(Hz2/Hz1)	Freq. set 2/ Freq. set 1	Frequency setting 2 is selected when Hz2/Hz1 is ON	
	(M2/M1)	Motor 2/Motor 1	Motor 1 settings take effect when M2M1 is OFF. Motor 2 settings take effect when M2M1 is ON.	

*1 Only valid when induction motor drive is in operation

Remarks

+24V (22-27V) Max 50mA

and Y1E is used

(*1)

(*1)

(*2)

Isolated from terminal 11 and Y1E Short circuit between terminal CM

Max. voltage: 27Vdc; max. current: 50mA, leak current: 0.1mA ***, ON voltage: within 2V(at 50mA)

Functions

Comes ON when motor overheating is detected by the PTC/NTC thermistor

Alarm signal is generated when time passes or start-up exceeds over the preset value

Comes ON when the system determines that a break will occur if terminal C1 input falls below 2mA

Comes ON when a current larger than the set value has been detected for the timer-set time

Outputs a brake engage/release signal

Comes ON when both (FAR) and (FDT) are ON

Function code data changes can only be made when the keypad

Turn DCBRK ON to start direct current braking

(WE-KP)	for KEYPAD	Function code data changes can only be made when the keypad is turned ON with WE-KP
(UP)	UP command	Output frequency increases while UP is ON
(DOWN)	DOWN command	Output frequency decreases while DOWN is ON
(Hz/PID)	PID control cancel	PID control is canceled when Hz/PID is ON (runs based on multistep frequency/keypad/analog input etc.)
(IVS)	Inverse mode changeover	Switch from analog frequency setting or PID control output signal (frequency setting) operation mode to forward/reverse operation. Reverse operation enabled when IVS is ON.
(LE)	Link enable (RS485, Bus)	Operates according to commands from RS-485 when LE is ON
(PID-RST)	PID integral/differential reset	Turn PID-RST ON to reset PID integration and differential values
(PID-HLD)	PID integral hold	Turn PID-HLD ON to hold PID differentiation
PLC	PLC terminal	Connect to PLC output signal power supply Common for 24V power
CM(2-terminal)	Common	Common for digital input signal
(PLC)	Transistor output power	Power supply for transistor output load (Max: DC 24V DC 50mA) (Caution: Same terminal as digital input PLC terminal)
Y1	Transistor output	Select one of the following signals for output: Short circuit when ON signal is output or open circuit when ON signal is output
(RUN)	Inverter running (speed exists)	Comes ON when the output frequency is higher than starting frequency
(FAR)	Speed/freq. arrival	Comes ON when the difference between output frequency and set frequency rises above the frequency arrival detection range (function code E30)
(FDT)	Speed/freq. detection	Comes ON when output frequency falls below operational level (function code E31). Tums OFF when it falls below operational level (function code E31) or hysteresis width (function code E32)
(LU)	Undervoltage detection	Comes ON when there is a run command and running has stopped due to insufficient voltage
(IOL)	Inverter output limit	Comes ON when the inverter is experiencing limited current, automatic deceleration, or limited torque operation
(IPF)	Auto-restarting	Comes ON during auto restart operation (after momentary power failure and until completion of restart).
(OL)	Overload early warning	Comes ON when the electronic thermal relay value is higher than the preset alarm level
(SWM2)	Switch to Motor 2	Comes ON when Motor 2 is selected by inputting a motor switch signal (M2/M1)
(TRY)	Auto-resetting mode	Comes ON during auto reset mode
(LIFE)	Lifetime alarm	Alarm signal is output according to lifetime assessment standards inside the inverter
(PID-CTL)	PID control in progress	Comes ON when PID control is in effect
(PID-STP)	PID low water volume stop in progress	Comes ON when low liquid level stop is in effect in PID control (also stops based on the status of input run command)
(RUN2)	Inverter output in progress	Comes ON when the inverter is running above startup frequency and DC braking is also in operation (Comes ON when the inverter main circuit (gate) is ON)
(OLP)	Overload preventive control	Comes ON when overload prevention control is operating
(ID2)	Current detection 2	Comes ON when a current larger than the set value (for ID2) is continuously detected for longer than the time set on the timer

Terminal Functions

Symbol

(DCBRK)

Terminal Name

DC brake command

Write enable

Category

Digital input

Transistor output

*1 Only valid when induction motor drive is in operation

(THM)

(BRKS)

(MNT)

(FARFDT)

(C1OFF) (ID)

*2 These functions can be supported by the inverters having a ROM version 0500 or later

Thermistor detected

Maintenance timer

Current detection

Frequency arrival/frequency detected

C1 terminal break detected

Brake signal

Terminal Functions

Terminal Functions

		-		
Category	Symbol	Terminal Name	Functions	Remarks
or output	(IDL)	Small current detection	Comes ON when a current smaller than the set value has been detected for the timer-set time	
nsist	(ALM)	Alarm relay (for any fault)	Alarm signal is output as the transistor output signal	
Trar	Y1E	Transistor output common	Common terminal for transistor output	Isolated from terminal 11 and CM
Relay output	30A, 30B, 30C	Alarm relay output (for any fault)	Outputs a no-voltage contact signal (1c) when the inverter stops the alarm Can select the same signal as the Y1 signal for multipurpose relay output · Can switch between alarm output through excitation operation and alarm output through non-excitation operation	Contact rating : AC250V, 0.3A, coso=0.3 DC48V, 0.5A
Analog output	FMA	Analog monitor	Output format: DC voltage (0–10V) Output can be performed in one of the following selected analog formats · Output frequency 1 (Before slip compensation) · Output frequency 2 (After slip compensation) · Output trequency 2 (After slip compensation) · Output trequency 2 (After slip compensation) · Output trequency 2 (After slip compensation) · Output current · Output voltage · Input power · PID feedback value · DC link circuit voltage · Analog output test · PID command · PID output	Gain setting between 0 and 300%
LINK		Built-in RJ-45 connector (RS-485 communication)	Any of the following protocols can be selected: • Dedicated keypad protocol (automatically selected) • Modbus RTU • Fuji dedicated inverter protocol • SX protocol (for PC loader)	Provides power to the keypad Includes terminator ON/OFF switch Communication data storage can be selected.(*2)

*2 These functions can be supported by the inverters having a ROM version 0500 or later

Terminal Functions

Terminal Arrangement

Main circuit terminals

Power source	Nominal Applied Motor (kW(HP))	Inverter Type	Reference
	0.1 (1/8)	FRN0001C2S-2	
	0.2 (1/4)	FRN0002C2S-2	Fig. A
	0.4 (1/2)	FRN0004C2S-2	1.9.74
	0.75 (1)	FRN0006C2S-2	
Three phone	1.5 (2)	FRN0010C2S-2	
200V	2.2 (3)	FRN0012C2S-2	Fig. B
2001	3.7 (5)	FRN0020C2S-2	
	5.5(7.5)	FRN0025C2S-2	Fig. F
	7.5(10)	FRN0033C2S-2	ing. L
	11(15)	FRN0047C2S-2	Fig. F
	15(20)	FRN0060C2S-2	rig. r
	0.4 (1/2)	FRN0002C2[]-4[]	
	0.75 (1)	FRN0004C2 -4	
	1.5 (2)	FRN0005C2 -4	Fig. B
	2.2 (3)	FRN0007C2 -4	
	3.7 (5)	FRN0011C2 -4	
Three shares	5.5(7.5)	FRN0013C2S-4	Fig. F
A00V	7.5(10)	FRN0018C2S-4	1 g. L
4004	11(15)	FRN0024C2S-4	Fig. F
	15(20)	FRN0030C2S-4	rig. i
	5.5(7.5)	FRN0013C2E-4E	Fig. G
	7.5(10)	FRN0018C2E-4E	rig. G
	11(15)	11(15) FRN0024C2E-4E	
	15(20)	FRN0030C2E-4E	rig. ri
	0.1 (1/8)	FRN0001C2□-7□	
	0.2 (1/4)	FRN0002C2[]-7[]	Fig. C
Single-phase	0.4 (1/2)	FRN0004C2□-7□	rig. C
200V	0.75 (1)	FRN0006C2[]-7[]	
	1.5 (2)	FRN0010C2[]-7[]	E . 0
	2.2 (3)	FRN0012C2□-7□	Fig. D
	0.1 (1/8)	FRN0001C2S-6U	
Single-phase	0.2 (1/4)	FRN0002C2S-6U	En C
100V	0.4 (1/2)	FRN0003C2S-6U	Fig. C
	0.75 (1)	FRN0005C2S-6U	



Screw size: M6, Tightening torque: 5.8N·m(51.3 lb-in)



External Dimensions

Standard Model



Inverter type

FRN0025C2S-2[]

FRN0033C2S-2

FRN0013C2S-4

FRN0018C2S-4

Three-phas 200V

Three-phase 400V

20 8198 20 9198 20 1298 20 1298



D

۵

D2

D1

۵





wer supply	Investor tures	Dimensions (mm(inch))				
voltage	inverser type	D	D1	D2		
ree-phase 200V	FRN0020C2S-2					
ree-phase 400V	FRN0011C2S-4	139(5.47)	75(2.95)	64(2.52)		
gle-phase 200V	FRN0012C2S-7					

12(0.47) 10(0.39) 688688888 TEL MILET Surger Street



[Unit : mm(inch)]

Power supply voltage	Inverter type
Three-phase 200V	FRN0047C2S-2
	FRN0060C2S-2
Three-phase 400V	FRN0024C2S-4
	FRN0030C2S-4



EMC Filter Built-in Model



Options

Name(Type) Braking resistor [Standard] (DB ...-2)



Specifications and dimensions [Unit:mm]									
w				_					
W1		T	ype	Fig.		Dimensions [mm]			
0	-	2007	400V		W	H	H1	07	[kg]
		DB0.75-2	DB0.75-4	A	00	310	290	0/	1.3
		DB2.2-2	-	A	80	345	332	94	2.0
도도		-	DB2.2-4	A	68	470	455	67	2.0
		DB3.7-2	-	A	80	345	332	94	2.0
1001		-	DB3.7-4	Α	68	470	455	67	1.7
		DB5.5-2		В	146	450	430	67.5	4.5
	Standard		DB5.5-4	В	146	470	455	67	4.5
	1120	DB7.5-2		В	160	390	370	90	5.0
		-	DB7.5-4	В	146	510	495	67	5.0
		DB11-2		С	142	430	415	160	6.9
R3.5		-	DB11-4	С	142	430	415	160	6.9
915		DB15-2	-	С	142	430	415	160	6.9
8			DB15-4	С	142	430	415	160	6.9
		DB0.75-2C	DB0.75-4C	D	43	221	215	30.5	0.4
		DB2.2-2C	DB2.2-4C	E	67	188	172	55	0.8
포 포		DB3.7-2C	DB3.7-4C	E	67	328	312	55	1.4
	10%ED	DB5.5-2C	DB5.5-4C	E	80	378	362	78	-
	1700	DB7.5-2C	DB7.5-4C	E	80	418	402	78	-
		DB11-2C	DB11-4C	F	80	460	440	140	-
1 Z		DB15-2C	DB15-4C	F	80	580	560	140	-

						Max	braking to	raue PS-1	Continuor	is braking	Repetitive	braking
-	Power				Resistance	marx.	50 [Hz]	60 [Hz]	(100% torque o	onversion value)	(100 sec or	less cycle)
Type supply voltage	Inverter type	Туре	Q'ty	[Ω]		[N·m]	[N-m]	Discharging capability [kWs]	Braking time [s]	Average loss [kW]	Duty cycle [%ED]	
		FRN0004C2S-2	DB0 75 0		100		4.02	3.32	9		0.044	22
	Three- phase	FRN0006C2S-2	DB0.75*2		100	40	7.57	6.25	17	45	0.068	18
		FRN0010C2S-2	DB2 2.2		40		15.0	12.4	34		0.075	10
		FRN0012C2S-2	DD2.2-2		40		22.0	18.2	33	30	0.077	7
	phase	FRN0020C2S-2	DB3.7-2	1	33	150	37.1	30.5	37		0.093	
	200 V	FRN0025C2S-2	DB5.5-2	1	20		55.1	45.4	55	20	0.138	1
		FRN0033C2S-2	DB7.5-2	1	15		75.1	61.9	37		0.188	5
		FRN0047C2S-2	DB11-2	1	10		110.2	90.8	55	10	0.275	1
		FRN0060C2S-2	DB15-2	1	8.6		150.3	123.8	75		0.375	
		FRN0002C2 -4	DB0 75 4		200		4.02	3.32	9		0.044	22
		FRN0004C2 -4	DB0.75-4		200		7.57	6.25	17	45	0.068	18
Standard		FRN0005C2 -4	00004		100		15.0	12.4	34		0.075	10
Type	Three-	FRN0007C2 -4	DB2.2-4	1	160		22.0	18.2	33	30	0.077	7
	phase	FRN0011C2 -4	DB3.7-4	1	130	150	37.1	30.5	37		0.093	
	400 V	FRN0013C2 -4	DB5.5-4	1	80	80 60	55.1	45.4	55	10	0.138	1
		FRN0018C2 -4	DB7.5-4	1	60		75.1	61.9	38		0.188	5
		FRN0024C28-4	DB11-4	1	40		110.2	90.8	55		0.275	
		FRN0030C28-4	DB15-4	1	34.4		150.3	123.8	75		0.375	
	Single	FRN0004C2 -7	0.00.75.0		100		4.02	3.32	9	45	0.044	22
	Single-	FRN0006C2 -7	DB0.75-2	1	100	150	7.57	6.25	17		0.068	18
	200 V	FRN0010C28-7	00000		40	150	15.0	12.4	34		0.075	10
	200 V	FRN0012C2 -7	DB2.2-2	1	40		22.0	18.2	33	30	0.077	7
	Single-phase	FRN0003C2S-6U	DB0 75 0		100	160	4.02	3.32	9		0.044	22
	100 V	FRN0005C2S-6U	DB0.75-2	1	100	150	7.57	6.25	17	45	0.068	18
		FRN0004C2S-2	DB0 75 00		100		4.02	3.32	50	250	0.075	37
		FRN0006C2S-2	080.75-20	1	100		7.57	6.25	50	133	0.075	20
		FRN0010C2S-2	000000				15.0	12.4		73	0.440	14
	Three-	FRN0012C2S-2	DB2.2-2C	1	40		22.0	18.2	55	50	0.110	
	phase	FRN0020C2S-2	DB3.7-2C	1	33	150	37.1	30.5	140	75	0.185]
	200 V	FRN0025C2S-2	DB5.5-2C	1	20		55.1	45.4	55	20	0.275	
		FRN0033C2S-2	DB7.5-2C	1	15		75.1	61.9	37		0.375	10
		FRN0047C2S-2	DB11-2C	1	10		110.2	90.8	55	10	0.55	
		FRN0060C2S-2	DB15-2C	1	8.6		150.3	123.8	75		0.75	
		FRN0002C2 -4	DB0 75 40		200		4.02	3.32	50	250	0.075	37
		FRN0004C2 -4	DB0.75-4C	1	200		7.57	6.25	50	133	0.075	20
10%ED		FRN0005C2 -4	000040		100		15.0	12.4		73	0.110	14
Type	Three-	FRN0007C2 -4	DB2.2-4C	1	160		22.0	18.2	- 55	50	0.110	
	phase	FRN0011C28-4	DB3.7-4C	1	130	150	37.1	30.5	140	75	0.185]
	400 V	FRN0013C2 -4	DB5.5-4C	1	80		55.1	45.4	55	20	0.275	
		FRN0018C2 -4	DB7.5-4C	1	60		75.1	61.9	38		0.375	10
		FRN0024C2 -4	DB11-4C	1	40		110.2	90.8	55	10	0.55	
		FRN0030C2 -4	DB15-4C	1	34.4		150.3	123.8	75		0.75	
	Cingle	FRN0004C2 -7	DB0.75-20	1	100		4.02	3.32	60	250	0.075	37
	phase	FRN0006C2 -7	0.00110.20		100	150	7.57	6.25	50 133	0.075	20	
	200 V	FRN0010C2 -7	DB2 2-20	1	40	100	15.0	12.4	66	73	0.110	14
		FRN0012C2 -7	000.0-00		40		22.0	18.2	55	50	0.110	10
	Single-phase	FRN0003C2S-6U	DB0 75-90	1	100	150	4.02	3.32	50	250	0.075	37
100 V	FRN0005C2S-6U	000.70-20		100	150	7.57	6.25	30	133	0.075	20	

Note: 1) A box (□) in the above table replaces A, C, E, or U depending on shipping destination. 2) A box (■) in the above table replaces S (Basic type) or E (EMC filter built-in type) depending on the enclosure.





Note 1: Generated losses listed in the above table are approximate values that are calculated according to the following conditions:

The power source is 3-phase 200 V/400 V 50 Hz with 0% interphase voltage unbalance ratio.
 The power source capacity uses the larger of either 500 kVA or 10 times the rated capacity of the inverter.
 The motor is a 4-pole standard model at full load (100%).

An AC reactor (ACR) is not connected.

Note 2:A box (
) in the above table replaces A, C, E, or U depending on shipping destination. Note 3:A box (
) in the above table replaces S (Basic type) or E (EMC filter built-in type) depending on the enclosure.

Options

Remote keypad (TP-E1)

The keypad permits remote control of FRENIC-Mini, and function setting and display (with copy function).





Using the keypad in combination with FRENIC Loader enables a variety of data about the inverter unit to be saved in the keypad memory, allowing you to check the information in any place.



Remote operation extension cable (CB- S)

This straight cable is used to connect the RS485 Communications card and the remote keypad, and available in three lengths, i.e. 1m, 3m and 5m.



Mounting adapters (MA-C1-DD)

FRENIC-Mini series of inverters	Ontion model	Applicable inverter model			
can be installed in the control	Option model	FRENIC-Mini	FVR-E11S		
board of your system using		FRN0001C2S-2	FVR0.1E11S-2		
mounting adapters which utilize		FRN0002C2S-2	FVR0.2E11S-2		
the mounting holes used for		FRN0004C2S-2	FVR0.4E11S-2		
conventional inverters (FVR-E11S series of 0.75 kW or below or 3.7	MA-C1-0.75	FRN0006C2S-2	FVR0.75E11S-2		
		FRN0001C2S-7	FVR0.1E11S-7		
		FRN0002C2S-7	FVR0.2E11S-7		
(4.0) KW). THE FVH-ETTS-2/4 (1.5		FRN0004C2S-7	FVR0.4E11S-7		
kW/2.2 kW) and FVR-E11S-7		FRN0006C2S-7			
(0.75 kW/1.5 kW) models may be		FRN0020C2S-2	FVR3.7E11S-2		
replaced with the FRENIC-Mini series inverters without the use of	MA-C1-3.7	FRN0011C2S-4	FVR3.7E11S-4		
	1111 01 0.1	FRN0012C2S-7	FVR4.0E11S-4		
adanters			FVR2.2E11S-7		

Note: A box (
) in the above table replaces A, C, E, or U depending on shipping destination.

Rail mounting bases (RMA-C1-

A rail mounting base allows any of the FRENIC-Mini series of inverter to be mounted on a DIN rail (35 mm (1.38 inches) wide).

Option model	Applicable inverter type
	FRN0001C2S-2
	FRN0002C2S-2
	FRN0004C2S-2
	FRN0006C2S-2
RMA-C1-0.75	FRN0001C2S-7
	FRN0002C2S-7
1.000	FRN0004C2S-7
1	FRN0006C2S-7
1 9 1	FRN0001C2S-6U
1	FRN0002C2S-6U
al a	FRN0003C2S-6U
	FRN0001C2E-7
	FRN0002C2E-7
	FRN0004C2E-7
	FRN0010C2S-2
	FRN0012C2S-2
RMA-C1-2.2	FRN0002C2S-4
	FRN0004C2S-4
	FRN0005C2S-4
1. 1.	FRN0007C2S-4
	FRN0010C2S-7
10	FRN0002C2E-4
	FRN0004C2E-4
	FRN0006C2E-7
DMA C1 27	FRN0020C2S-2
HIMA-CT-3.7	FRN0011C2S-4
	FRN0012C2S-7
5.	FRN0005C2E-4
8.	FRN0007C2E-4
N	FRN0011C2E-4
R.	FRN0010C2E-7
	FRN0012C2E-7

Note 1: A box (
) in the above table replaces A, C, E, or U depending on shipping

destination. Note 2: This rail mounting base is not suitable for the inverters of 5.5 kW (7.5 HP) or above.

Mounting the NEMA1 kit	Figure B	Power supply voltage	Inverter type	Option type	Figure
on the FRENIC-Mini			FRN0001C2S-2	NEMA1-C2-101	
the inverterie enclosure		Three-phase 200 V	FRN0004C2S-2	NEMA1-C2-102	^
the inverter's enclosure	0.		FRN0006C2S-2	NEMA1-C2-103	
into compliance with the	6 AT		FRN0010C2S-2	NEMA1-C2-201	В
NEMA1 Standard (UL	No No		FRN0012C2S-2		
TYPE1 certified)			FRN0020C2S-2	NEMA1-C2-301	С
TTT ET GOTUNGO).		Three-phase 400 V	FRN0002C2S-4	NEMA1-C2-202	٨
			FRN0004C2S-4	NEMA1-C2-203	^
			FRN0005C2S-4	NEMA1-C2-201	В
	¥ 7		FRN0007C2S-4		
			FRN0011C2S-4	NEMA1-C2-301	C
Figure A	Figure C	Single-phase 200 V	FRN0001C2S-7	NEMA1-C2-101	A
			FRN0002C2S-7		
			FRN0004C2S-7	NEMA1-C2-102	
	0.4		FRN0006C2S-7	NEMA1-C2-104	
10V.T			FRN0010C2S-7	NEMA1-C2-204	В
NO / N			FRN0012C2S-7	NEMA1-C2-301	C
		Single-phase 100 V	FRN0001C2S-6U	NEMA1-C2-105	A
	1 I I I I I I I I I I I I I I I I I I I		FRN0002C2S-6U		
N			FRN0003C2S-6U	NEMA1-C2-106	
			FRN0005C2S-6U	NEMA1-C2-205	1

This option is not applicable to the EMC filter built-in type or inverters of 5.5 kW or above.

NEMA1 kit (NEMA1- C2-)

Wiring equipment

Power supply voltage	Applicable motor rating [kW]	Inverter type	MCCB, ELCB Rated current [A]		Magnetic contactor type MC1 (for input circuit)		Magnetic contactor type MC2 (for output	Recommended wire size (mm2) at 50°C (122°F) or below				
			DC reactor (DCR)		DC reactor (DCR)			Main circuit power input [L1/R , L2/S , L3/T] or [L1/L, L2/N]		Inverter	DC reactor	Braking
			w/ DCR	w/o DCR	w/ DCR	w/o DCR	circuit)	w/ DC reactor (DCR)	w/o DC reactor (DCR)	[U, V, W]	[P1, P(+)]	[P(+), DB]
Three- phase 200 V	0.1	FRN0001C2S-2	5 (6)	5 (6)	SC-05	SC-05	SC-05	2.0 (2.5)	2.0 (2.5)	2.0 (2.5)	2.0(2.5)	
	0.2	FRN0002C2S-2										
	0.4	FRN0004C2S-2										2.0 (2.5)
	0.75	FRN0006C2S-2		10								
	1.5	FRN0010C2S-2	10	15 (16)								
	2.2	FRN0012C2S-2		20 (25)]					1		
	3.7	FRN0020C2S-2	20 (25)	30 (35)		SC-5-1	· · · · · · · · · · · · · · · · · · ·		5.5 (6)	3.5 (4)	3.5 (4.0)	
	5.5	FRN0025C2S-2	30 (35)	50	SC-4-0	SC-5-1	SC-4-0	5.5 (6)	8 (10)	5.5 (6)	5.5 (6)	
	7.5	FRN0033C2S-2	40	75	SC-5-1	SC-N1	SC-5-1	8 (10)	14 (16)	8 (10)	14 (16)	
	11	FRN0047C2S-2	50	100	SC-N1	SC-N2S	SC-N1	14 (16)	22 (25)	14 (16)	22 (25)	
	15	FRN0060C2S-2	75	125	SC-N2	SC-N3	SC-N2	22 (25)	38 (50)	22 (25)	38 (50)	
	0.4	FRN0002C2 -4	5 (6)	5 (6)	SC-05	SC-05	SC-05	2.0 (2.5)	2.0 (2.5)	2.0 (2.5)	2.0 (2.5)	2.0 (2.5)
	0.75	FRN0004C2 -4										
	1.5	FRN0005C2 -4		10								
Three-	2.2	FRN0007C2 -4		15 (16)								
phase	3.7/4.0	FRN0011C2 -4	10	20 (25)								
400 V	5.5	FRN0013C2 -4	15 (16)	30 (35)					3.5 (4)			
	7.5	FRN0018C2 -4	20 (25)	40		SC-4-0			5.5 (6)	3.5 (4)	3.5 (4)	
	11	FRN0024C2 -4	30 (35)	50	SC-4-0	SC-N1	SC-4-0	5.5 (6)	8 (10)	5.5 (6)	5.5 (6)	
	15	FRN0030C2 -4	40	60	SC-5-1		SC-5-1	8 (10)	14 (16)	8 (10)	14 (16)	
Single- phase 200 V	0.1	FRN0001C2 -7	5 (6)	5 (6)	SC-05	SC-05	SC-05	2.0 (2.5)	2.0 (2.5)	2.0 (2.5)	2.0 (2.5)	-
	0.2	FRN0002C2 -7										
	0.4	FRN0004C2 -7		10								2.0 (2.5)
	0.75	FRN0006C2 -7	10	15 (16)								
	1.5	FRN0010C2 -7	15 (16)	20 (25)					3.5 (4.0)			
	2.2	FRN0012C2 -7	20 (25)	30 (35)		SC-5-1		3.5 (4.0)	5.5 (6.0)		3.5 (4.0)	
Single- phase 100 V	0.1	FRN0001C2S-6U	5 (6)	5 (6)	SC-05	SC-05	SC-05	2.0 (2.5)	2.0 (2.5)	2.0 (2.5)	•	-
	0.2	FHN0002C2S-6U	10	10								0.0 (0.5)
	0.4	FRN0003C2S-6U	10	15 (16)								2.0 (2.5)
	0.75	FRN0005C2S-6U	15 (16)	20 (25)					3.5 (4.0)			

Note) The symbol ■ is replaced with either of the following letters ■: S (Standard type), E (EMC filter built-in type) •For molded-case circuit breakers (MCCB) and earth-leakage circuit breakers (ELCB), the required frame type and series depend on the facility transformer capacity and other factors. When selecting optimal breakers, refer to the relevant technical data. Also select the rated sensitive current of ELCB utilizing the technical data. •The recommended wire sizes are based on the temperature inside the panel not exceeding 50°C. •The above wires are 600V HIV insulated solid wires (75°C). •Data in the above table may differ accortding to environmental conditions (ambient temperature, power supply voltage, and other factors).

MEMO

High Perfomance Compact Body Welcome to the NEXT Generation of Compact

MEMO

When running general-purpose motors

- Driving a 400V general-purpose motor
 When driving a 400V general-purpose motor with an inverter using extremely long cables, damage to the insulation of the motor may occur. Use an output circuit fitter (OFL) if necessary after checking with the motor manufacturer. Fuji's motors do not require the use of output circuit filters because of their reinforced insulation.
- Torque characteristics and temperature rise When the inverter is used to run a general-purpose motor, the temperature of the motor becomes higher than when it is operated using a commercial power supply. In the low-speed range, the cooling effect will be weakened, so decrease the output torque of the motor. If constant torque is required in the low-speed range, use a Fuji inverter motor or a motor equipped with an externally powered ventilating fan.

Vibration

When the motor is mounted to a machine, resonance may be caused by the natural frequencies, including that of the machine. Operation of a 2-pole motor at 60Hz or more may cause abnormal vibration.

* Study use of tier coupling or dampening rubber.

* It is also reconvnended to use the inverter jump frequencies control to avoid resonance points.

Noise

When an inverter is used with a general-purpose motor, the motor noise level is higher than that with a commercial power supply. To reduce noise, raise carrier frequency of the inverter. High-speed operation at 60Hz or more can also result in more noise.

When running special motors

• Explosion-proof motors

When driving an explosion-proof motor with an inverter, use a combination of a motor and an inverter that has been approved in advance.

Brake motors

For motors equipped with parallel-connected brakes, their braking power must be supplied from the primary circuit (commercial power supply). If the brake power is connected to the inverter power output circuit (secondary circuit) by mistake, problems may occur.

Do not use inverters for driving motors equipped with series connected brakes.

Geared motors

If the power transmission mechanism uses an oillubricated gearbox or speed changer/reducer, then continuous motor operation at tow speed may cause poor lubrication. Avoid such operation.

Single-phase motors

Single-phase motors are not suitable for inverterdriven variable speed operation. Use three-phase motors.

Environmental conditions

Installation location

Use the inverter in a location with an ambient temperature range of -10°C (14°F) to 50°C (122°F). The inverter and braking resistor surfaces become hot under certain operating conditions. Install the inverter on nonflammable material such as metal. Ensure that the installation location meets the environmental conditions specified in "Environment" in inverter specifications.

Combination with peripheral devices

Installing a molded case circuit breaker (MCCB)

Install a recommended molded case circuit breaker (MCCB) or an earth leakage circuit breaker (ELCB) in the primary circuit of each inverter to protect the wiring. Ensure that the circuit breaker capacity is equivalent to or lower than the recommended capacity.

 Installing a magnetic contactor (MC) in the output (secondary) circuit

If a magnetic contactor (MC) is mounted in the inverter's secondary circuit for switching the motor to commercial power or for any other purpose, ensure that both the inverter and the motor are fully stopped before you turn the MC on or off. Remove the surge killer integrated with the MC.

Installing a magnetic contactor (MC) in the input (primary) circuit

Do not turn the magnetic contactor (MC) in the primary circuit on or off more than once an hour as an inverter fault may result. If frequent starts or stops are required during motor operation, use FWD/REV signals.

Protecting the motor

The electronic thermal facility of the inverter can protect the general-purpose motor. The operation level and the motor type (general-purpose motor, inverter motor) should be set. For high-speed motors or water-cooled motors, set a small value for the thermal time constant to protect the motor.

If you connect the motor thermal relay to the motor with a long cable, a high-frequency current may flow into the wiring stray capacitance. This may cause the relay to trip at a current lower than the set value for the thermal relay. If this happens, lower the carrier frequency or use the output circuit filler (OFL).

- Discontinuance of power-factor correcting capacitor Do not mount power factor correcting capacitors in the inverter (primary) circuit. (Use the DC REACTOR to improve the inverter power factor.) Do not use power factor correcting capacitors in the inverter output circuit (secondary). An overcurrent trip will occur, disabling motor operation.
- Discontinuance of surge killer

Do not mount surge killers in the inverter output (secondary) circuit.

• Reducing noise

Use of a filter and shielded wires are typical measures against noise to ensure that EMC Directives are met.

Measures against surge currents

If an overvoltage trip occurs while the inverter is stopped or operated under a light load, it is assumed that the surge current is generated by open/close of the phase-advancing capacitor in the power system.

We recommend connecting a DC REACTOR to the inverter.

Megger test

When checking the insulation resistance of the inverter, use a 500V megger and follow the instructions contained in the Instruction Manual.

Wiring

• Wiring distance of control circuit

When performing remote operation, use twisted shielded wire and limit the distance between the inverter and the control box to 20m (65.6ft).

• Wiring length between inverter and motor If long wiring is used between the inverter and the motor, the inverter will overheat or trip as a result of overcurrent (highfrequency current flowing into the stray capacitance) in the wires connected to the phases. Ensure that the wiring is shorter than 50m (164ft). If this length must be exceeded, lower the carrier frequency or mount an output circuit filter (OFL). When wiring is longer than 50m (164ft), and sansorless vector control or vector control with speed sensor is selected, execute off-line tuning.

• Wiring size

Select cables with a sufficient capacity by referring to the current value or recommended wire size.

Wiring type

Do not use multicore cables that are normally used for connecting several inverters and motors.

Grounding

Securely ground the inverter using the grounding terminal.

Selecting inverter capacity

Driving general-purpose motor

Select an inverter according to the applicable motor ratings listed in the standard specifications table for the inverter. When high starting torque is required or quick acceleration or deceleration is required, select an inverter with a capacity one size greater than the standard.

• Driving special motors

Select an inverter that meets the following condition: Inverter rated current > Motor rated current.

Transportation and storage

When transporting or storing inverters, follow the procedures and select locations that meet the environmental conditions that agree with the inverter specifications.

